


# Doro 2820


## Quick Start Guide



English



- 1. Speaker
- 2. Left selection button
- 3. Navigation keys
- 4. Camera shortcut
- 5. Call button
- 6. Voicemail
- 7. International prefix/Symbols
- 8. Microphone
- 9. Right selection button
- 10. Message shortcut
- 11. OK-button
- 12. End call/Power on/off
- 13. Input method/Silent mode



- 14. Camera flash and torch
- 15. Red light = battery level low / charging
- 16. Green light = New message / missed call
- 17. Camera lens
- 18. Second microphone
- 19. Assistance button
- 20. Headset socket
- 21. Charging socket
- 22. Loudspeaker
- 23. Volume keys

**Note!** All illustrations are for illustrative purposes only and may not accurately depict the actual device. The items supplied with your phone might vary depending on the software and accessories available in your region or offered by your service provider. You can obtain additional accessories from your local Doro dealer. The supplied accessories provide the best performance with your phone.

**IMPORTANT!** Your device may use data services and you may incur additional charges for data services, such as messaging or using location services depending on your data plan. We recommend that you check your data rates for your subscription with your service provider.

### 1. GET STARTED

When you get your phone, first remove the screen protector.

#### 1.1. Unbox your new phone

Start by taking your new phone and all included items out from the box. Also read through the manual so that you can familiarize yourself with the equipment and the basic functions. For full manual please visit [www.doro.com](http://www.doro.com) or contact our Helpline.

- The items supplied with the device and any available accessories may vary depending on the region or service provider.
- Appearances and specifications are subject to change without prior notice.
- You can purchase additional accessories from your local Doro retailer. Make sure they are compatible with the device before purchase.
- Only use batteries, chargers and accessories that have been approved for use with this model. Connecting other accessories may be dangerous and may invalidate the type approval and warranty.
- Availability of all accessories is subject to change depending entirely on manufacturing companies. For

more information about available accessories, refer to the Doro website.


- Availability of all accessories is subject to change depending entirely on manufacturing companies. For more information about available accessories, visit [www.doro.com](http://www.doro.com) or contact our Helpline.

#### 1.2. Insert the memory card, SIM card and battery

**Important!** Turn off the phone and disconnect the charger before removing the battery cover.


**Remove the battery cover:** There is a small dent on the back of the phone. Pull this gently to open the battery cover.

**Important!** Be careful not to damage your fingernails when you remove the battery cover. Do not bend or twist the battery cover excessively as it may get damaged.



#### Insert the SIM card:

Insert the micro SIM card from your mobile service provider. Make sure that the contacts of the SIM card are facing inwards and that the cut off corner is as shown. Be careful not to scratch or bend the contacts on the cards when inserting them into the card holders.



**Tip:** If it is difficult to remove or replace the SIM card you can use adhesive tape on the exposed part of the SIM card to pull it out.

#### Insert the memory card:

If you want you can install a memory card to increase the storage space of your phone. This will allow you to store more files, pictures and videos. Make sure that the contacts of the memory card are facing downwards, as shown above.

**Note!** This device only accepts micro SIM card (3FF). Use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card.

Use only compatible memory cards with this device. Compatible card types include microSD, microSDHC, microSDXC. Incompatible memory cards may damage the card itself, the device and corrupt any data stored on the card.

#### Insert the battery:

Insert the battery with the contacts facing upwards to the left. Put the battery cover back in place.



#### 1.3. Charge

We recommend that you charge the phone fully before you use it the first time.

**Caution** Only use batteries and accessories that have been approved for use with this particular model. Connecting other accessories may be dangerous and may invalidate the phone's type approval and warranty.

When the battery is running low, appears and a warning signal is heard. Connect a mains adapter to a wall socket and to the charging socket or place the device in a charging cradle. You can also connect a cable to the charging socket on the phone and to a USB port on a computer.

**Note:** To protect the environment we might not provide chargers and USB-cables with all our products. Your device supports charging with a USB-C cable and a USB charger that is compliant with applicable country regulations and international and regional safety standards, such as UKCA or CE. Do not use USB chargers that do not meet applicable safety standards. If you use another charger, the power delivered by the charger must be between minimum 0,60

Watts required by the radio equipment, and maximum 2,75 Watts in order to achieve the maximum charging speed. The USB-C charging port does not have audio capability and will not support connection of a USB-C headset.

#### 1.4. Save energy

When the battery is fully charged, disconnect the charger from the device and unplug the charger from the wall socket. To save power the screen goes off after a while. Press any button to wake the screen up. Batteries degrade over time, which means that call time and standby time will normally decrease with regular use. During extended operation, the device may feel warm. In most cases, this is normal. To avoid getting too warm, the device may switch off during charging.

#### 1.5. Turn the phone on and off

1. Press and hold the red button on the phone to turn it off. Confirm with **OK**. To turn the phone on again, press and hold the red button again.
2. If the SIM card is valid but protected with a PIN code (Personal Identification Number), **PIN code** is displayed. Enter the PIN code and press **OK**. Delete with **Clear** ( right selection button).

**Note!** If PIN and PUK codes were not provided with your SIM card, please contact your service provider.  
**Attempts: #** shows the number of PIN attempts left. When no more attempts remain, **PIN blocked** is displayed. The SIM card must now be unlocked with the PUK code (Personal Unblocking Key).

1. Enter the PUK code and confirm with **OK**.
2. Enter a new PIN code and confirm with **OK**.
3. Re-enter the new PIN code and confirm with **OK**.

### 2. GET TO KNOW YOUR PHONE

When starting the telephone for the first time, you are guided by the Start-up wizard to set some basic settings. Select the setting you would like to change. When ready, press **Done**.

#### 2.1. Descriptions in this document

Descriptions in this document are based on your phone setup at the time of purchase. Instructions normally start from the home screen. Press (red) to reach the home screen. Some descriptions are simplified.

The arrow () indicates next action in a step-by-step instruction.

#### 2.2. Handle the phone

##### Selection buttons :

**Contacts :** Press to see your contacts. This is displayed as the right selection button in idle screen.

**Options button :** Press to see more options available in selected menu. This is displayed as the left selection button in selected menus.

**Back :** Return to the previous screen. This is displayed as the right selection button in selected

menus.

**Call (green):**

- Dial a number or answer an incoming call.
- Enter the call log.

**End call/Power on and off (red):**

- Press to end calls or return to the home screen.
- Long press to power on or off.

**Assistance (o):**

- Press to make an assistance call.

**Camera :**

- Press to initiate the camera app.

**Message :**

- Press to initiate the messaging app.

**2.3. Navigation keys:**

- Use the navigation keys to navigate up and down.
- Use the centre button (with “OK” on it) to open the main menu, select items and confirm actions. This button will be shown as **OK** in the rest of this document.

**Note!** Navigation in some apps from other developers might work differently.

**Volume control:** Use buttons on the side of the device to adjust the sound volume. During a phone call, it adjusts the earpiece volume.

**Set the language:** The default language is determined by the SIM card.

Go to **Menu** **Settings** **General** **Language** **Language** and choose the preferred language by pressing **OK**.

**Set the time and date:** The time and date can automatically be set from the network.

Go to **Menu** **Settings** **General** **Time & date**. Here you can select **Set time** or **Set date**. You can also automatically set time and date provided by your network operator. Select **Automatic date & time** **Use network-provided time**.

**2.4. Enter text**

- Press the button corresponding to the letter until the appropriate character appears.
- Press for a list of special characters. Select the desired character using the navigation keys and press **OK** to enter it.
- Use the navigation keys to move the cursor within the text.
- Press **Clear** to erase characters.
- Press to select upper case (ABC), lower case (abc), sentence case (Abc), numerals (123) and predictive text (language code).

**Enter text with predictive text:** In some languages you can use the predictive text input method which uses a dictionary to suggest words. Just press the button corresponding to the appropriate character and then select the suggested word with the navigation keys. Confirm the selected word with **OK**.

While texting, press to change input method.

**Change the writing language:**

1. Press and scroll down to **Writing language** for a list of available languages.
2. Select language and press **OK** to confirm.

**Enter phone numbers:**  
**Note!** For international calls, always use + before the country code for best operation. Press twice for the international prefix +.

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or credit card billing numbers. There are two types of pauses available on your phone, press repeatedly until desired character is shown. **P** is for pause and **W** is to wait for user activation.

### 3. CALLS

**3.1. Make a call**

1. Enter the phone number.
2. Press (green) to call.
3. Press (red) to end the call.

  
**Note!** There is no dial tone. As long as the phone is turned on, it is ready for use.

**3.2. Make a call from the contacts list**

1. Press or press **OK** **Contacts**.
2. Use the navigation key to scroll through the contacts, or press **Search contact** to search the phonebook.
3. Select the wanted contact and press (green). Alternatively, select the wanted contact and press **OK** **Call** to select a secondary number stored to that contact.

**3.3. Receive a call**

1. To answer an incoming call when the phone is closed, open the phone. Press (green) to answer. Alternatively press **Silent** to switch off the ringsignal or press or close the flip to reject directly (this will send a busy signal to the caller).

**3.4. Silence an incoming call**  
When a call comes in, press any of the **Volume** keys to silence the ring tone.

**3.5. Call log**  
Received, missed, and dialed calls are saved in a call log.  
**Retrieving and dialing:**

1. Press (green).
2. Use the navigation keys to scroll through the call log
  - = Incoming call
  - = Outgoing call
  - = Missed call
3. Press (green) to dial the highlighted number.

### 4. CONTACTS

**4.1. Create a contact**

1. Press **Menu** **Contacts** **Add contact**
2. Choose if you want to save your contacts on your phone or on your SIM card.
3. Enter relevant contact information.

4. When done, press **Save**.  
**Tip:** Depending on the selected storage location, the types of information you can save may vary.

**4.2. Create ICE entry (In Case of Emergency)**  
First responders can access additional information such as medical information from the phone of the victim in case of emergency. In the event of a trauma, it is critical to have this information as early as possible to increase the chances of survival. All fields are optional, but the more information provided the better.

1. Press **Menu** **Contacts** **ICE**.
2. Fill in as much information as possible.
3. Select information field and press **Edit**, fill in your information and press **Save** when done.

### 5. SOS/112 CALLS

As long as the phone is switched on, it is always possible to place an SOS call by entering the main local emergency number for your present location followed by (green). Some networks accept calls to emergency numbers without a valid SIM card. Contact your service provider for more information.

**Note!** Sometimes an emergency call cannot be placed due to network, environment or interference issues.

**6. ASSISTANCE BUTTON (o)**  
**Important!** If the Assistance call is answered by a voice mail or answering service, the alarm call is considered confirmed and no further call attempts will be made (assistance sequence is interrupted).

The Assistance button on the back of the phone allows easy access to your predefined help contacts (Helpers) in case of emergency. Make sure that the assistance function is activated before use. See the full manual for more information about the function.

**6.1. Activation**  
Activate the function for the assistance button.

1. Press **OK/Menu** **Assistance** **Activation**:
  - **On normal** to press and hold the button for approximately 3 seconds, or press it twice within 1 second.
  - **On (3)** to press the button 3 times within 1 second.
  - **Off** to disable the assistance button.
2. Press to go back and continue with other settings.

**6.2. Helpers**  
Add help contacts (Helpers) to the list that are called when the assistance button is pressed.

1. Press **OK/Menu** **Assistance** **Helpers**.
2. Select **Add** **Manual** to add names and numbers manually. You can also press **Contacts** to select from your stored contacts.
3. Press to go back and continue with other settings.

**6.3. Assistance SMS**  
A text message can be sent to the Helpers when the assistance button is pressed.

1. Press **Menu** **Assistance** **Assistance SMS**.
2. Check **Send SMS** to activate the feature.
3. Use the navigation key down to go to the message field. Here you can write the message that will be sent to the

contacts you have chosen as helpers when you press the assistance button. It is helpful to them if you write that this is an emergency message from you. Example: "This is an emergency message from John Smith."

4. Press **Save** to save the message.
5. Press to go back and continue with other settings.

  
**Note!** You must write a message if you activate the Assistance SMS function. Always inform recipients in the Helpers list that they are listed as your assistance contacts.

**6.4. Signal type**  
Select the notification signal type for the assistance sequence.

1. Press **Menu** **Assistance** **Signal type**:
  - **High** to use loud signals (default).
  - **Low** to use one low signal.
  - **Silent** no sound indication, like a normal call.
2. Press to go back and continue with other settings.

**7. CAMERA**

1. Press the shortcut button or, press **Menu** **Camera**.
2. Press or **OK** to take a photo.

**8. MESSAGES**  
**8.1. Create a message**  
An SMS is a short text message that can be sent to other mobile phones. A picture message, or MMS, can contain text and media objects such as pictures, sound recordings and video. The settings for messaging are supplied by your

service provider and can be sent to you automatically via text message. If you choose to send to multiple contacts, you will be charged for each one.

1. Press or press **Menu** **Messages** **Write**.
2. Enter the recipients phone number manually in the field on top, or press the left selection button to select and go to your contacts. Press **Select** **Done**.
3. Scroll down and type your message.
4. Press for further options (like add a picture, video or other).
5. When done, press **Send**.

**Important!** Some features uses Internet data services and that can be costly. We recommend that you check your data service rates with your service provider.

**9. CUSTOM SETTINGS**  
**9.1. Silence the ring tone**  
Press and hold to activate/deactivate silent. During an incoming call, press **Volume** keys to silence the ring tone.

**9.2. Configure the audio setup**  
If you use a hearing aid or have hearing difficulties when using the device in a noisy environment, you can adjust the audio settings.  
**Press Menu** **Settings** **Sound** **Audio setup**.

